



THANKS FOR PURCHASING ONE OF OUR SOUND RIGS.
IN YOUR BOX YOU WILL FIND THE BELOW



8 Button mounted glove & Board
1.5m 3.5mm Jack Aux Cable (with right angle connection)
1.5m USB to Micro USB cable
MicroSD Card Converter (only needed for adding new profiles)

In addition, you will require:

1. Speaker with 3.5mm aux port.
2. USB Power bank



IMPORTANT – Please do not wrap the ribbon cable around the hand unit for storage. Whilst this device is made to last this can cause unnecessary strain on the connection to the PCB and may result in damage and the device stopping working.

How To Guide:

When powering on the Pro, ensure your speaker is connected first before connecting power. The main reason for this is when the Pro boots up it will announce the character in the 'Profile 1' position. This confirms the device is working as expected.

- **Click & Hold Buttons** – Where applicable there will be different dialogue on some of your buttons. Consult the Template that you would have been provided. A single click will activate the 'Click' sounds and a short hold will activate the 'Hold' sounds.
- **Switching Profiles** – If you have purchased and installed additional profiles they will be loaded in order on your device. Each device can have upto 6 profiles. Hold Button 1 and then Hold button 8 there will be an audio announcement of the profile you have switched to. If you move to an empty profile, there will just be an audible bleep.
- **Polyphonic Sounds** – If your template has this option, you can hold Button 8 to activate the sound (Music or Vader breathing) Release Button 8 once it starts. Whilst the Polyphonic audio is playing you can still play the other sounds. To stop the audio Hold Button 8 once again.

To see the above in action, visit our YouTube site for a demonstration video.
[Youtube.com/@EngageSoundRig](https://www.youtube.com/@EngageSoundRig)